

Mounting instruction

ECOFLEX 10® / AIRCOM PLUS® N-Angle-Connector / Art. Nr.: 7360



Cut off cable tail right-angled.



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.




Remove 16 mm of the outer sheath with a knife.



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.



Mark out and remove the copper foil with a knife. Short the dielectric to a length of 10 mm.



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 17/18 mm. A small split should remain visible between clamping nut and connector housing. Then the inner conductor has to be soldered to the center contact.



Screw down closure cap firmly.

